

N G

E E

T N

W E

O R

R A


K L

**Expert Analysis
Application
Quick Reference
Card**

Overview of Menu Options

This guide provides an overview of most options in the Sniffer analysis application's menus. These illustrations show the analysis application's factory defaults. Choose the Use Defaults command to restore these values at any time.

First Level



Ethernet only.


Second Level



Second Level

Third Level

Fourth Level



FDDI only.

Second Level

- x Known stns only
- x Unknown stns only

Destination class

- / Broadcast
- / Specific

Station address

Match 1

From <any station>
To <any station>

/ Reverse direction

► Include these
Exclude these

(same)
(same)
(same)
Include others
Exclude others

Protocol

- / LOOP Etype
- / Netmap TCP Etype
- / Netmap XNS Etype
- / IBMRT Etype
- / NetWare Etype
- / XNS Etype

More↓

Pattern match

Match 1

Frame-relative
Data-relative

AND

Match

OR

Don't match

Match 2

Either offset

AND

Pattern xxxx
Offset=000

OR

Pattern xxxx
Offset=000

Match 3

Hexadecimal
Character
Binary

AND

OR

Match 4

- / From DTE
- / From DCE
- / RR Frames
- / RNR Frames
- / Info Frames
- / Good frames
- / Bad CRC frames
- / Short frames
- / Collision frames
- / Error frames

Will vary depending on network.
Internetwork Analyzer (WAN/Synchronous).

Third Level

- / Match 2
- / Match 3
- / Match 4
- Others

Protocol

- / LOOP Etype
- / Netmap TCP Etype
- / Netmap XNS Etype
- / IBMRT Etype
- / NetWare Etype
- / XNS Etype

More↓

Pattern match

Match 1

Frame-relative
Data-relative

AND

Match

OR

Don't match

Match 2

Either offset

AND

Pattern xxxx
Offset=000

Match 3


Hexadecimal
Character
Binary

AND


OR

Match 4

Trigger Menus




Sniffer Network Analyzer only (not present on DSS).
Will vary depending on network.
Internetwork Analyzer (WAN/Synchronous).
Token ring only.




Sniffer Network Analyzer for Ethernet only (not present on DSS).


Display Menus




Sniffer Network Analyzer only (not present on DSS).
DSS only.




Expert Config Menus



DSS only.
Internetwork Analyzer (WAN/Synchronous).
Token ring only.



**CORPORATE HEADQUARTERS**

NETWORK GENERAL CORPORATION
4200 BOHANNON DRIVE
MENLO PARK, CA 94025 USA
TEL: (415) 473-2000

NETWORK GENERAL EUROPE

BELGICA STRAAT 4
1930 ZAVENTUM, BELGIUM
TEL: 32 (2) 725-6030

NETWORK GENERAL CANADA, LTD.

9225 LESLIE STREET, UNIT #7
RICHMOND HILL, ONTARIO L4B 3H6 CANADA
TEL: (905) 882-7905